







Serial No.	DRT-A626/1096010-1022	Contact Person	YUYI
------------	-----------------------	----------------	------

Customer		Product	DRT overhaul
Test Date		Maker/model	DRT-A626
		Serial Number	1096010-1022

項目Item	內容描述/Content description	備註/Note.
異常狀況 Abnormal condition	無訊號，雷達圖打不開 No signal, radar chart cannot be opened	
產品外觀檢查 Appearance inspection	產品外觀檢查正常/Pass	
主要功能檢驗 Main function inspection	<p>1.上機測試故障雷達圖打不開，無信號/ On-board test failure radar chart can not be opened, no signal</p>  <p>2.打開DRT進行檢查，RT部分正常(如右圖)-----> RT part is normal (as shown in the right picture)</p>	
檢驗結果 Test result	<p>DRT主板有毀損,需要更換零件,探頭部分亦有毀損 The DRT motherboard is damaged, parts need to be replaced, and the probe part is also damaged</p>	
維修內容 Repair content	<p>1.更換DRT主電路板內部零件Replace the internal parts of the DRT main circuit board</p>  <p>2.探頭部分，發現有晶片損壞，更換(如右圖)-----></p>	
維修後檢驗 Test after Repair	<p>1.組裝上電測試，連接在測試電腦上DRT雷達可以打開，圖像如下</p> 	<p>2.裝在機台測試DRT雷達圖可以打開，也有迴曲率</p> 